



HD 650 V5
Sicherheitshinweise

# Inhaltsverzeichnis

1. Über diese Anleitung	03
2. Bestimmungsgemäßer Gebrauch	03
3. Erklärung von Symbolen und Warnhinweisen	03
4. Allgemeine Sicherheitshinweise	03
5. Sicherheit für Kinder	04
6. Knopfzellen-Batterie (CR2025)	04
7. Betrieb, Umgebung & mechanische Beanspruchung	04
8. Nutzung im Straßenverkehr und an gefährlichen Orten	05
9. Reinigung & Pflege	05
10. Entsorgung (ElektroG)	05
11. Hinweise zu Batterien/Akkus (BattG)	05
12. Technische Kurzangaben	06

## 1. Über diese Anleitung

Diese Anleitung enthält wichtige Informationen zur sicheren Verwendung des Fernsehers (nachfolgend "Produkt").

- Vor der ersten Verwendung alle Hinweise vollständig lesen und aufbewahren.
- Bei Weitergabe des Produkts diese Sicherheitshinweise mitgeben.
- Die Nichtbeachtung kann zu Verletzungen oder Sachschäden führen.

# 2. Bestimmungsgemäßer Gebrauch

Das Produkt dient zum Empfang frei empfangbarer DVB-S/S2 Programme sowie zur Nutzung von Multimedia-Funktionen (USB-Mediaplayer, EPG, Videotext).

Jede andere Nutzung gilt als nicht bestimmungsgemäß und kann zu Schäden führen.

# 3. Erklärung von Symbolen und Warnhinweisen

- Symbole und Signalwörter weisen auf Restgefahren hin.
- Warnhinweise stehen vor gefährlichen Handlungsschritten.
- Alle Warnhinweise beachten und befolgen.

# 4. Allgemeine Sicherheitshinweise

- Reparaturen/Wartung nur durch Fachpersonal.
- Nur Original-Zubehör verwenden.
- Nationale Vorschriften und ggf. örtliche Bestimmungen beachten.

#### 5. Sicherheit für Kinder

- Lebensgefahr durch Verschlucken von Kleinteilen (z. B. Batterie, Verpackung).
- Produkt ist kein Spielzeug.
- Nicht geeignet für Kinder unter 3 Jahren.
- Reinigung/Wartung nicht von Kindern durchführen lassen.

### 6. Knopfzellen-Batterie (CR2025)

In der Fernbedienung befindet sich eine Lithium-Knopfzelle (CR2025).

#### Lebensgefahr durch Verschlucken

- Verschlucken kann lebensgefährlich sein.
- Batterien außerhalb der Reichweite von Kindern aufbewahren.
- Bei Verdacht auf Verschlucken: sofort Arzt aufsuchen.Ladezeit ca. 2 Std.; Gerät nicht dauerhaft unbeaufsichtigt am Netz belassen.

#### **Umgang mit Batterien**

- Nur CR2025-Batterien gleichen Typs verwenden.
- Batterie nicht aufladen, kurzschließen, zerdrücken, erhitzen oder ins Feuer werfen – Explosions- und Brandgefahr!
- Batterie fachgerecht und polrichtig einsetzen.
- Leere Batterien umgehend entfernen, um Auslaufen zu vermeiden.

#### Kontakt mit ausgelaufenen Stoffen

- Hautkontakt: sofort mit viel Wasser abwaschen.
- Augenkontakt: mindestens 15 Minuten spülen, sofort Arzt aufsuchen.
- Verschlucken oder Einatmen: umgehend medizinische Hilfe in Anspruch nehmen.

# 7. Betrieb, Umgebung & mechanische Beanspruchung

- Netzspannung: nur an 100–240 V~, 50/60 Hz betreiben.
- Gerät nicht abdecken; Lüftungsschlitze freihalten.
- Vor Feuchtigkeit, direkter Sonne, Stößen schützen.
- Keine Flüssigkeiten ins Gerät eindringen lassen.

### 8. Nutzung im Straßenverkehr und an gefährlichen Orten

 Das Produkt darf nicht während der Fahrt oder an Orten verwendet werden, an denen Ablenkung zu Gefahren führen kann.

### 9. Reinigung & Pflege

- Gerät vor Reinigung vom Stromnetz trennen.
- Nur weiches, trockenes Tuch verwenden.
- Keine lösungsmittelhaltigen Reinigungsmittel oder Flüssigkeiten ins Gerät eindringen lassen.

### 10. Entsorgung (ElektroG)

Elektrische/elektronische Altgeräte nicht über den Hausmüll entsorgen; einer getrennten Sammlung/Verwertung zuführen.

- Symbol durchgestrichene Mülltonne beachten.
- Abgabe bei kommunalen Sammelstellen oder autorisierten Rücknahmestellen.
- Personenbezogene Daten auf Altgeräten vor Abgabe selbst löschen.

#### 11. Hinweise zu Batterien/Akkus (BattG)

- Batterien getrennt sammeln, nicht im Hausmüll entsorgen.
- Symbol durchgestrichene Mülltonne beachten.
- Knopfzellen enthalten Lithium; unsachgemäße Entsorgung kann Umwelt und Gesundheit schädigen.

# 12. Technische Kurzangaben

- Stromversorgung: AC 100–240 V~, 50/60 Hz
  Verbrauch im Betrieb: max. 8 W
- Verbrauch im Standby: < 0,5 W</li>
- Fernbedienung: Betrieb mit 1x Lithium-Knopfzelle CR2025

#### Konformitätsinformation

Hiermit erklärt die Firma Megasat Werke GmbH, dass sich folgende Geräte in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinien befinden:

- 2014/30/EU (EMV)
- 2014/35/EU (LVD)

Megasat HD 650 V5 (Art.-Nr. 0201157)

Die vollständige Konformitätserklärung liegt bei der Megasat Werke GmbH vor und ist online abrufbar unter: www.megasat.tv/support/downloads



#### Haftungsausschluss

Diese Bedienungsanleitung wurde mit größter Sorgfalt erstellt. Dennoch übernehmen wir keine Haftung für eventuelle Irrtümer, Druckfehler oder fehlerhafte Angaben. Änderungen und technische Weiterentwicklungen vorbehalten. Die Nutzung erfolgt auf eigene Verantwortung.

#### Symbole und Hinweise



Altgeräte dürfen nicht über den Hausmüll entsorgt werden. Sie sind zur Abgabe alter Elektro- und Elektronikgeräte bei den kommunalen Sammelstellen gesetzlich verpflichtet. Batterien und Akkus müssen vor der Entsorgung entnommen und fachgerecht entsorgt werden.

WEEE-Reg.-Nr.: DE70592344



Die Verpackung dieses Produkts besteht aus umweltverträglichen Materialien, die wiederverwertet werden können. Bitte entsorgen Sie Verpackung und Füllmaterialien entsprechend den örtlichen Vorschriften zur Abfalltrennung.





HD 650 V5 safety instructions

# **Table of contents**

1. About this guide	03
2. Intended use	03
3. Explanation of symbols and warnings	03
4. General safety instructions	03
5. Safety for children	04
6. Button cell battery (CR2025)	04
7. Operation, environment & mechanical stress	04
8. Use in road traffic and in dangerous places	05
9. Cleaning & care	05
10. Disposal (ElektroG)	05
11. Notes on batteries/rechargeable batteries (BattG)	05
12. Brief technical information	06

### 1. About this guide

These instructions contain important information on the safe use of the television (hereinafter referred to as the "product").

- Read all the instructions in full before using the product for the first time and keep them in a safe place.
- Pass on these safety instructions when passing on the product.
- Failure to do so may result in injury or damage to property.

#### 2. Intended use

The product is intended for the reception of free-to-air DVB-S/S2 programmes and for the use of multimedia functions (USB media player, EPG, teletext).

Any other use is considered improper and may result in damage.

## 3. Explanation of symbols and warnings

- Symbols and signal words indicate residual dangers.
- Warnings precede dangerous actions.
- Observe and follow all warnings.

## 4. General safety instructions

- Repairs/maintenance only by specialised personnel.
- Only use original accessories.
- Observe national regulations and, if applicable, local regulations.

### 5. Safety for children

- Danger to life from swallowing small parts (e.g. battery, packaging).
- Product is not a toy.
- Not suitable for children under 3 years of age.
- Do not allow children to carry out cleaning/maintenance.

#### 6. Button cell battery (CR2025)

The remote control contains a lithium button cell (CR2025).

#### Danger to life due to ingestion

- Ingestion can be fatal.
- Keep batteries out of the reach of children.
- If ingestion is suspected: consult a doctor immediately. charging time approx. 2 hours; do not leave the device permanently unattended on the mains.

#### **Handling batteries**

- Only use CR2025 batteries of the same type.
- Do not charge, short-circuit, crush, heat or throw the battery into a fire risk of explosion and fire!
- Insert the battery correctly and with the correct polarity.
- Remove empty batteries immediately to prevent leakage.

#### **Contact with leaked substances**

- Skin contact: wash off immediately with plenty of water.
- Eye contact: rinse for at least 15 minutes, seek medical attention immediately.
- Ingestion or inhalation: seek medical attention immediately.

## 7. Operation, environment & mechanical stress

- Mains voltage: only operate on 100-240 V~, 50/60 Hz.
- Do not cover the appliance; keep the ventilation slots clear.
- Protect from moisture, direct sunlight and impact.
- Do not allow any liquids to enter the appliance.

04 ENGLISH

#### 8. Use in road traffic and in dangerous places

• The product must not be used while driving or in places where distraction can lead to danger.

### 9. Cleaning & care

- Disconnect the appliance from the power supply before cleaning.
- Only use a soft, dry cloth.
- Do not allow any cleaning agents or liquids containing solvents to penetrate the appliance.

### 10. Disposal (ElektroG)

Do not dispose of old electrical/electronic appliances with household waste; dispose of them separately for collection/recycling.

- Note the crossed-out wheelie bin symbol.
- Hand in at municipal collection points or authorised take-back points.
- Delete personal data on old appliances yourself before handing them in.

### 11. Notes on batteries/rechargeable batteries (BattG)

- Collect batteries separately, do not dispose of in household waste.
- Note the crossed-out wheelie bin symbol.
- Button cells contain lithium; improper disposal can damage the environment and health.

### 12. Brief technical information

- Power supply: AC 100-240 V~, 50/60 Hz
   Consumption during operation: max. 8 W
   Consumption in standby mode: < 0.5 W</li>
   Remote control: Operation with 1x lithium button cell CR2025

06 **ENGLISH** 

#### **Conformity information**

Megasat Werke GmbH hereby declares that the following devices are in conformity with the essential requirements and the other relevant provisions of the directives:

- 2014/30/EU (EMV)
- 2014/35/EU (LVD)

Megasat HD 650 V5 (Art.-No. 0201157)

The complete declaration of conformity is available from Megasat Werke GmbH and can be accessed online at: www.megasat.tv/support/downloads



#### Disclaimer

These operating instructions have been compiled with the utmost care. Nevertheless, we accept no liability for any errors, misprints or incorrect information. We reserve the right to make changes and further technical developments. Use is at your own risk.

#### Symbols and notes



Old appliances must not be disposed of with household waste. You are legally obliged to dispose of old electrical and electronic equipment at municipal collection centres. Batteries and rechargeable batteries must be removed and disposed of properly before disposal.

WEEE-Reg.-Nr.: DE70592344



The packaging of this product consists of environmentally friendly materials that can be recycled. Please dispose of packaging and filling materials in accordance with local regulations on waste separation.